



ZEBRA



Device Tracker

Track and recover devices anywhere within or beyond the four walls

Your mobile devices are crucial for your business success. When they go missing, you risk productivity loss, decreased efficiency, unnecessary labor and ineffective customer service. Ultimately, your devices are only as valuable as their availability.

That's where Zebra Device Tracker comes in. Device Tracker makes it easy to keep track of all your Zebra mobile computers, tablets and wearables, so that your teams are always ready to go when they are needed.

Zebra Device Tracker is easy to deploy and can scale to virtually any size fleet. Your team has everything they need to track, monitor and flag devices using predefined automated workflows. What if your misplaced device is powered down? No problem. By purchasing Zebra Bluetooth® Low Energy (BLE) batteries, you expand Device Tracker's capability to locate devices after they power off due to low charge.

Recovery shouldn't be confined to the walls of your facility. With Map-Based Locationing, precisely geolocate and view every connected WLAN or WAN Zebra device with Device Tracker on Google Maps. A proximity indicator on another device will guide you to the lost device, and you can also trigger an alarm on the missing device to assist in recovery.

Protect against loss by setting thresholds that automatically flag devices at risk of loss. Single sign-on enables transparent accountability and security during check-out and check-in. Gain unparalleled fleet visibility with a dashboard that provides the exact location and status of your entire fleet. With customizable status and incident reports, you can understand and quantify the impact device loss has on your business.

Take complete ownership of your devices and empower your workforce with Zebra Device Tracker.



Benefits

Eliminate lost or misplaced Zebra Android™ mobile devices to:

Maximize device availability and value

Maximize workforce productivity

Maximize Return on Investment (ROI)

Features



No-Hassle, Cloud-Based Deployment

Easy to download via your EMM or Zebra StageNow.



Scale for Any Size Deployment

Device Tracker supports over 5,000 sites and 100,000 devices.



Portal and Dashboard Information

View precise device locations and customizable reports at your fingertips.



Check-Out/In Accountability

Identify device users with simple barcode or single sign-on (SSO) compatibility.



Map-Based Locationing

With the click of a button, precisely geolocate and view your devices on Google Maps




Intuitive User Interface

A simple proximity indicator lets you know how close the device is- and guides you there.



Workflow Automation

Set thresholds for when devices are at risk and flag them to be recovered.



Manager Screens

STOREA41	
Last Updated 03/25/2022, 04:30PM	
Total Devices	2
Low Battery	0
To Be Found	1
Being Found	0
Found	0
Cannot Find	0
Charging	1
Discharging	1

Manager Site Dashboard—Overview:

Provides site managers with a status overview of all devices at their site.


STOREA41	
Last Updated 03/25/2022, 04:30PM	
Found	0
Cannot Find	0
Charging	1
Discharging	1
Decommissioned	0
Never Connected	0
Disconnected	0
Checked Out	2

Device Tracker	
Disable Finding	Start Finding
Device Details	
Status	To Be Found
Friendly Name	
Device Model	TC77
Serial Number	181155225E0192
License State	Licensed
Site Name	STOREA41

Manager Site Dashboard—Device Details:

Allows managers to quickly and easily view the details of connected devices in a specific location.

General Features



Device Check-Out:

When users are mandated to scan their employee badge to access a device, managers have visibility into which associate has which device, resulting in more accountability.

Zebra Device Tracker	
To Be Found in NEW YORK	
INVENTORY#2	DAVID M
	TC57 (S/N:18301522508714)
	HOME AREA
	To Be Found
STOCKING#2	ELIZABETH G
	TC72 (S/N:18317522506625)
	BACK OFFICE AREA
	To Be Found

Find Device Work Orders:

Displays all devices at a site that need to be recovered.

Zebra Device Tracker	
Device Model	TC72
Serial Number	18317522506625
Connected AP	BACK OFFICE AREA
Proximity	Signal Good
	7.9
Far	Close
Play Sound	
Cannot find	Device found

Proximity Indicator/Geiger-Counter:

Indicates whether users are moving closer to or farther from a lost device; enables activation of the “Play Sound” function.

Administrator Screens

Zebra Device Tracker

All Devices

Unassigned Devices

Sites:

BOSTON

BUFFALO

CHICAGO

COLUMBUS

DALLAS

Administrator Screens:

Administrators can view Device Tracker on a mobile device or a desktop computer. The ability to view information on a mobile device allows Administrators to monitor information anywhere and anytime. For example, the screen on the left presents all sites, and allows Administrators to drill down into any site for details. The intuitive interface allows even inexperienced Administrators to easily create users. And activating features, such as device check-out/check-in, just takes one click. And an easy-to-use dashboard provides the up-to-date status of all devices at a glance.

Mobile Devices

All Devices

7	0	0	3	7	0	0	0	0	2	0
Total	To Be Found	Charging	Discharging	In Service	Being Found	Found	Decommissioned	Cannot Find	Disconnected	Never Connected

2	0	0
Checked Out	Low Battery	Idle

Actions

Device Name	Serial #	Device Model	Last Used By	Location	Status	Connection	Battery %	Charging
INVENTORY#1	202405225D0031	EC30	PETER	Garden Area	In Service	Not Connected	97	Not charging
INVENTORY#2	202405225D0100	EC30	JENNY	Clothing Area	In Service	Not Connected	27	Not charging

Zebra Device Tracker

demoadmin@zebra.com

Manage Users

Settings

About

Application Configuration

Checkin/Checkout: Enabled

Prefix: YK12-

Save

Eliminate the high cost of lost and misplaced Zebra Android mobile devices in your organization with Zebra Device Tracker. For more information, visit www.zebra.com/devicetracker



NA and Corporate Headquarters
+1 800 423 0442
inquiry4@zebra.com

Asia-Pacific Headquarters
+65 6858 0722
contact.apac@zebra.com

EMEA Headquarters
zebra.com/locations
contact.emea@zebra.com

Latin America Headquarters
zebra.com/locations
la.contactme@zebra.com

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corp., registered in many jurisdictions worldwide. Android is a trademark of Google LLC. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG Inc., and any use of such marks by Zebra is under license. All other trademarks are the property of their respective owners. © 2024 Zebra Technologies Corp. and/or its affiliates. All rights reserved. 02/15/2024.