LDX10 Batch Data Collection Handheld Quick-Start Guide

Physical Features

24-key Keypad

800.648.4452
www.amltd.com
MADE IN USA
01132017-1

AML

LCD

Scan Key

Power Button

Scan Engine Window

Top

USB Port

Bottom

T9 Keypad

Getting Started

1 Charge the LDX10 for 6 hours

Use the supplied USB cable and power adapter to charge from a 110VAC wall outlet.

* Phone chargers may or may not work properly with the LDX10 due to possible differences in charging currents. In addition, USB ports on desktop computers/laptops are also inadequate for charging and should not be used.

Getting Started

2 Starting up the LDX10
Power and Reboot Procedures

Power Button

• Pressing the power button while the LDX10 is OFF powers up and re-boots the unit.

• While charging, the LDX10 display will go dark after a time set in the 'Display Properties' settings in Windows® Control Panel. Touching the screen or any key will awaken it from this idle state.

• If left idle for 30 minutes, the LDX10 will automatically power down.

• Pressing the power button briefly, while the unit is on, will either put the LDX10 into suspend mode, or wake it up depending on its current state.

• Pressing and holding the power button for more than 3 seconds causes the LDX10 to power off.

Getting Started

3 Download DC Console

dc CONSOLE

Utilize **DC Console** to quickly modify existing applications or create new ones and transfer files from your LDX10 to your PC.

Download the DC Console utility at
www.amltd.com/Software/DC-Software

The LDX10 comes with a suite of pre-installed applications as a part of our **DC Suite**. These applications were developed for common data collection tasks and are ready to go right out of the box.

As future applications are developed, they will be made available on the web at barcodepower.com.

Dashboard
All applications are launched from here.

DC Suite 2:16 PM
Item Count | Item Quantity | Item Serial
Item Lot Quantity | Asset Tracker | Compare
Check In/Out

Settings

DC Suite 2:28 PM
Item_Count

Item

Item
735854862749
1234567890982
12345670
01234565
012345678905

Record 5/5 | HOME | VIEW

Simple one-field scanning.

Scan the Item Number and key in the Quantity.

DC Suite 2:22 PM
Item_Serial

Item

Serial Number

Item	Serial Number

Record 0/0 | HOME | VIEW

*Scan in Item Number and the unique Serial Number.*

Scan the Item Number and then collect Lot Number and Quantity information.

DC Suite 2:23 PM
Item_Quantity

Item

Quantity

Item	Quantity

Record 0/0 | HOME | VIEW

DC Suite 2:23 PM
Item_Lot_Quantity

Item

Lot

Quantity

Item	Lot	Quantity

Record 0/0 | HOME | VIEW

DC Suite 2:24 PM
Asset_Tracker

Location

Asset ID

Location	Asset ID

Record 0/0 | HOME | VIEW

Asset Tracking application.

DC Suite 2:24 PM
Verifier

Lot Item

Item

HOME

Compare two scans and confirm that they are the same OR not the same.

DC Suite 2:25 PM
CheckInOut

○ IN
● OUT

User ID

Tool ID

User ID	Tool ID	Status	TimeStamp

Record 0/0 | HOME | VIEW

Check-In/Out application for tool or part rooms.

Accessories

Support

Protective Cases

Red
(Standard)
Black
Orange
Yellow
Blue
Green

Learn More About the LDX10 at:
www.amltd.com/ldx10

For **DC Suite** downloads and support visit:
www.amltd.com/Software/DC-Software

Warranty Agreements

SVC-EWLDX10	Extended Warranty, 3 year, LDX10
SVC-EWPLDX10	Extended Warranty PLUS, 3 year, LDX10

Get Updates from AML
Don't forget to register your product(s) online at
www.amltd.com/register to receive updates about AML products and software.

CE | FC | TESTED TO COMPLY WITH FCC STANDARDS | RoHS

AML

2190 Regal Parkway
Euless, TX 76040
800.648.4452
www.amltd.com